

Calculating Safe Distances - An Application of Presence Sensing Devices

written by Lauri Moon | October 22, 2018

The effectiveness of particular types of safeguards depends in part on the correct positioning of the relevant parts in relation to the danger zone. ISO 13855 primarily defines human approach speeds. These approach speeds need to be considered when designing safety measures and selecting the appropriate sensor technology. Different speeds and sizes are defined, depending on the direction and type of approach. Even an indirect approach is considered.

Viewers will learn:

- Safe distance formulas for different presence sensing devices
- Calculation techniques of stop time
- Application standards used for presence sensing devices

Sponsored by



Register

By clicking above, I acknowledge and agree to Informa's Terms of Service and to Informa's use of my contact information to communicate with me about offerings by Informa, its brands, affiliates and/or third-party partners, consistent with Informa's Privacy Policy. In addition, I understand that my personal information will be shared with any sponsor(s) of the resource, so they can contact me directly about their products or services. Please refer to the privacy policies of such sponsor(s) for more details on how your information will be used by them.